

INDUSTRIAL OVENS

Drying, curing, ageing etc.,
applications



EO SERIES



Curing, drying, ageing, annealing or any heat processing tests at higher temperatures
Envisys has the oven to meet your needs

Whether it is a standard conventional drying application using shelves or conveyor drying or drying through infrared bulbs Envisys provides all types of drying solutions with custom configured designs and sizes

Exterior chamber made of CRCS 18/16 gauge with CNC fabrication with powder coated panels for long life usage

Modular-Custom Design configurations built-to requirements

Inner Chamber made of Stainless Steel 304 grade 18 gauge optional 16 gauges

Inner and outer chamber filled with rock wool slabs of high density and low thermal conductivity

Provided with control panel for control & monitoring of temperature

CONTROL FEATURES

Microprocessor based PID controller with precise temperature control
External timer for cut off of operation (Optional)
Blind High temperature safety cut-off within the unit
Solid state control relays for heating power control
Etc.,



ENVISYS

reimagining the environment

ENVISYS TECHNOLOGIES PVT LTD

ISO 9001-2008 Certified Company

#32, Ligadi Mansion, Muthurayaswamy Layout, Sunkadakatte,
Bangalore – 560091 Karnataka INDIA

E-mail: www.envisys tech.com Phone: +91 80 65770603,
7411455246, 9880953742 Website: www.envisys tech.com